


IF A RESET SWITCH IS NOT  
 FITTED TO THE AR1500  
 ADD A DIODE (AND SERIES  
 SWITCH IF PERMANENTLY  
 MOUNTING) AS INDICATED  
 ON THIS PCB LAYOUT



13  
 14  
 15  
 16  
 17  
 18  
 19  
 20

D300 272  
 D302 272  
 D301 272  
 D303 272

C300 150P 68  
 C301 150P 67  
 C302 66  
 104 65  
 64  
 63  
 62  
 61  
 E  
 54  
 53  
 52

DIODE FOR RESET.